

SPIT INSTRUCTIONS



How to light the spit:

- Ensure spit is placed on a solid, flat surface
- Place a fat container under drain outlet at the motor end of the spit (not provided)
- Ensure the bar is secured with the Motor Pin clip at the motor end of the spit
- Plug motor into mains power
- Ensure both control knobs are in the OFF position
- Ensure the lid is lifted white lighting
- Ensure the regulator is firmly attached to the bottle to avoid gas leaks
- Turn on gas at cylinder
- Push the control knob in and turn to HIGH, whilst also pressing the ignition button (a spark clicking sound should be heard). This will light the burner
- Repeat the above step for the second burner
- Adjust the heat to the desired level by turning the knob between the high and low position
- Turn motor on using power switch on the motor, and the bar will start spinning
- Once cooking is complete, turn both control knobs to OFF and turn the gas bottle off






Cleaning:

- Please remove the tinfoil AFTER use. Clean spit with hot, soapy water before returning
- **Fail to do this, you will incur an \$100 cleaning charge**

Safety instructions/General info:

- The motor is rated for up to 60kg
- 30 watt, 240 volt, 10 amp plug
- Do not move the spit whilst cooking or when the wheels are locked.
- The animal must be balanced on the bar to prevent an uneven spinning pattern.

You will receive the below in a box to secure the animal on the bar:

	<p><u>U SHAPED MEAT PRONG X2</u></p> <p>The U shaped meat prong is used inside the ribcage and poked through the animal, on either side of the spine to pull the spine closer to the bar to achieve bar balance.</p>
	<p><u>MEAT PRONG X2</u></p> <p>The meat prongs are to be poked into the hind quarter and fore quarter from the outside to attach them to the bar.</p>
	<p><u>TRIANGLE SUPPORT X2</u></p> <p>To be used inside the ribcage to prevent the ribcage from collapsing during the cooking process.</p>
	<p><u>CARVING STAND X2</u></p> <p>On completion of cooking, open the lid, and these slot into the box section on each end of the spit. The bar can be lifted and placed into the grooves to make carving the animal easier. (Please note, that one stand has a square groove which goes on the motor end of the spit and the other has a round groove that goes at the control end. The square section of the bar fits into the square groove to prevent the bar spinning while carving).</p>
	<p><u>MOTOR PIN X1</u></p> <p>This will be attached to the spit, please ensure this is put back after use.</p>